



(717) 354-8998 • (877) 560-5966  
New Holland, PA


# #322D Bistro Settee



## Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket

## Included Hardware

A		4 1 1/2" Screws
---	-------------------------------------------------------------------------------------	-----------------

## Instructions:

1. Use instructions from #321Bistro Chair to assemble chairs.
2. With the two chairs setting upright, line up the table with the arms. Keep point flush with the round part of the arm rest. Fasten using 2 (A) 1 1/2" Screws. (Illustration 1)
3. Fasten the back of the table to the arms using 2 (A) 1 1/2" Screws. (Illustration 2)



Illustration 1



Illustration 2