

## #642 Easy Glider



## **Tools Required**

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16" Wrench

## Included Hardware

Α		10	1/4" x 3" Carriage Bolt
В		18	1⁄4" Nut
С		8	1/4" x 3" Lag Bolt
D	Samuel Control of the	8	1/4" x 3 1/2" Carriage Bolt

## Instructions:

- 1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
- To begin, line up the back section of your glider with the seat (Illustration 2)
- Install (8) ¼" x 3" carriage bolts (A) into the pre-drilled holes to attach the seat and back together. (Illustration 2)
- 4. Install (4) ¼ x 3 ½" Carriage bolts through the legs, attaching them to the seat with (D). Repeat on other side.
- 5. Install 3" Carriage bolts (A) securing glider arm to the back support. (Illustration 3) Repeat on other side.
- Install glider base bracing with 4 ¼ x3" (C) Lags. Repeat on other side. (Illustration 5)







