

FANBACK SERIES  
ASSEMBLY INSTRUCTIONS



(717) 354-8998 • (877) 560-5966  
New Holland, PA

#701 Ottoman



Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. With the ottoman laying upside, fasten the legs. Line up the pre-drilled holes and fasten using 4 (A) ¼" x 2½" Carriage Bolts & 4 (A) ¼" Nuts. (Illustration 2)



Illustration 2

Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

<b>A</b>		4	¼" x 2½" Carriage Bolt
<b>B</b>		4	¼" Nut