

FANBACK SERIES  
ASSEMBLY INSTRUCTIONS



(717) 354-8998 • (877) 560-5966  
New Holland, PA







#119 Fanback Swivel Glider



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

A		8	1/4" x 3" Carriage Bolt
B		8	1/4" Nut
C		4	1/4" x 1 1/2" Lag Bolt
D		2	1/4" x 3" Lag Bolt
E		6	2" Screws
F		8	2 1/2" Screws

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. To begin, set the seat upright. Set the back into the seat. Keep the back flush and pull tight to seat slat. Fasten using 2 (E) 2" Screws. (Illustration 2) Repeat on the other side.
3. Lay the chair on its back and fasten the legs of the arm/leg combo to the seat base using 4 (A) 1/4" x 3" Carriage Bolts & 4 (B) 1/4" Nuts. Then using a 1 (D) 1/4" x 3 1/2" Lag Bolt fasten the arm to the back seat brace. (Illustration 3)
4. Now turn chair upside down so it is resting on the arms. Line up the pre-drilled holes and fasten the glider rails using 4 (F) 2 1/2" Screws. Repeat on the other side. (Illustration 4)
5. With the chair still upside down, fasten the stopper using 2 (E) 2" Screws. (Illustration 5)
6. Now take the swivel base and set it upright. Rotate the swivel plate 45°. (Illustration 6)
7. Turn the swivel base upside down and align with the pre-drilled holes on the bottom of the glider. Fasten using 4 (C) 1/4" x 1 1/2" Lag Bolts. (Illustration 7)



Illustration 2




Illustration 3




Illustration 4




Illustration 5




Illustration 6




Illustration 7