

FANBACK SERIES ASSEMBLY INSTRUCTIONS








#442 Curve back Glider



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16" Wrench

Included Hardware

A		8	1/4" x 2 1/2" Carriage Bolt
B		18	1/4" Nut
C		8	1/4" x 3 1/2" Lag Bolt
D		8	1/4" x 3 1/2" Carriage Bolt
E		2	1/4" x 3" Carriage Bolt

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. To begin, line up the back section of your glider with the seat (Illustration 2)
3. Install (8) 1/4" x 2 1/2" carriage bolts into the pre-drilled holes to attach the seat and back together. (Illustration 2)
4. Install (4) 1/4 x 3 1/2" Carriage bolts through the legs, attaching them to the seat with (A). Repeat on other side.
5. Install 3" Carriage bolt (A) securing glider arm to the back support. (Illustration 3) Repeat on other side.
6. Install glider base bracing with 4 (C) Lags. Repeat on other side. (Illustration 4)



Illustration 2





Illustration 3




Illustration 4